
Diamond Drilling Tool

To avoid damage when temperatures below 4° are expected, the cooling system must be fully drained by blowing out with a blow out device.

Step by step blow-out:

- 1. Fit the blow-out adapter to the hose on the pump
- 2. Connect the water flow regulator
- 3. Set the 3-way valve to the wet drilling position
- 4. Connect the pump to the water connections
- 5. Operate the pump (at least 8 full strokes) until no further water is ejected from the tool
- 6. Leave the water flow regulator open

Always carefully observe the indications on the information labels and read the instruction manual



Recommended items for blowing out the tool.



For more information please call or visit Hilti Online.





