

Diamond Wall Saw

To avoid damage when temperatures below 4° are expected, the cooling system must be fully drained by blowing out with a blow out device.

Step by step blow-out:

1. Fit the blow-out adapter to the hose on the pump
2. Connect the pump to the water connections
3. Operate the pump (at least 8 full strokes) until no further water is ejected from the tool
4. Repeat above in the the bypass function at the saw head

Always carefully observe the indications on the information labels and read the instruction manual

At temperatures below zero, allow the machine to warm up slowly before subjecting to load and drain (blow out) the water from the cooling circuit after use (a pump is supplied for this purpose).

Recommended items for blowing out the tool.



Order 60579



Order 382894



For more information please call or visit Hilti Online.