

MIC-SC-MA 304817

Hilti North America Installation Technical Manual Technical Data MI System

Version 1.2 08.2017



Terms of common cooperation / Legal disclaimer

The product technical data published in these Technical Data Sheets are only valid for the mentioned codes or technical data generation methods and the defined application conditions (e.g. ambient temperature load capacity not valid in case of fire, data not valid in support structures when mixed with third party products, values only apply to static loading conditions). Technical data applies to the component only -- suitability and capacity of all other components must be checked separately by the responsible engineer (e.g., other assembly components, attachments, base materials, and building structures).

Suitability of structures combining different products for specific applications needs to be verified by conducting a system design and calculation, using for example Hilti PROFIS software. In addition, it is crucial to fully respect the Instructions for Use and to assure clean, unaltered and undamaged state of all products at any time in order to achieve optimum performance (e.g. avoid misuse, modification, overload, corrosion).

As products but also technical data generation methodologies evolve over time, technical data might change at any time without prior notice. We recommend to use the latest technical data sheets published by Hilti.

In any case the suitability of structures combining different products for specific applications need to be checked and cleared by an expert, particularly with regard to compliance with applicable norms, codes, and project specific requirements, prior to using them for any specific facility. This book only serves as an aid to interpret the capacity of the components listed, without any guarantee as to the absence of errors, the correctness and the relevance of the results or suitability for a specific application. User must take all necessary and reasonable steps to prevent or limit damage. The suitability of structures combining different products for specific applications need to be confirmed with a professional designer and/or structural engineers to ensure compliance with User's specific jurisdiction and project requirements.



| Designation | Item number |
|-------------|-------------|
| MIC-SC-MA | 304817 |

Corrosion protection:

Hot dipped galvanized per DIN EN ISO 1461:Connector:2.2 mils (55 μm)Bolt:1.8 mils (45 μm)Nut:1.8 mils (45 μm)

Weight:

20.72 lb (9400 g) incl. components


Description:

Hilti Hot-dipped galvanized baseplate connector, typically used for anchoring a MI-90 girder to a steel beam at an angle, usually when it's used as a brace for another girder. Four oblong anchor holes enable fine tuning of baseplate position, and girder is connected using one bolt through a hole, which enables various angles. For use with **M16** hardware.

| 1/2" (12) 1/2" (12.5) 3-1/8" (80) 1/4" (6) 3-15/16" 2-3,8"×1/2" (100) (60×13) (220) |
|--|
| Hardware included per connector |

| Yield strength | Ultimate strength | E-modulus | Shear modulus |
|--|---|--|---|
| | | | |
| $f_y = 34.08 \text{ ksi} (235 \frac{N}{mm^2})$ | $f_u = 52.21 \text{ ksi} (360 \frac{N}{mm^2})$ | E = 29000 ksi (20 | $0000 \frac{N}{mm^2}$) G = 11000 ksi (75845 $\frac{N}{mm^2}$) |
| | | | |
| $f_y = 92.82 \text{ ksi} (640 \frac{N}{mm^2})$ | $f_u = 116.03 \text{ ksi} (800 \frac{N}{mm^2})$ |) E = 29000 ksi (20 | $0000 \frac{N}{mm^2}) G = 11000 \text{ ksi } (75845 \frac{N}{mm^2})$ |
| | $f_y = 34.08 \text{ ksi} (235 \frac{N}{mm^2})$ | $f_y = 34.08 \text{ ksi} (235 \frac{N}{mm^2})$ $f_u = 52.21 \text{ ksi} (360 \frac{N}{mm^2})$ the hex nut | $f_y = 34.08 \text{ ksi} (235 \frac{N}{mm^2})$ $f_u = 52.21 \text{ ksi} (360 \frac{N}{mm^2})$ E = 29000 ksi (20 |

Instruction For Use:



Installation Technical Manual - Technical Data - MI system



| Approved load | ling cases | |
|---------------|------------|--|
| Clamped | Boxed | |
| | | |

Governing Conditions

Methodology:


Connection strength values are determined with a combination of simulation (ANSYS[®]), calculation (Microsoft Excel and Mathcad) and testing.

Standards and codes:

| - | | | |
|---|-----------------------|--|---------|
| • | ANSI/AISC 360-10 | Specification for Structural Steel Buildings | |
| • | ANSI/AISC 360-10- | Inelastic analysis | |
| | Appendix 1 | | |
| • | AISC Steel Design | Column Base Plates | |
| | Guide Series 1 | | |
| • | AISI S100 - 2007/2010 | North American Specification for the Design of cold | |
| | | formed Steel Structural Members | |
| • | ACI 318-08/11 | Building Code Requirement for Structural Concrete | |
| • | EN 1993-1-1 | Eurocode 3: Design of steel structures – Part 1-1: | 03.2012 |
| | | General rules and rules for buildings | |
| • | EN 1993-1-8 | Eurocode 3: Design of steel structures – Part 1-8: | 03.2012 |
| | | Design of joints | |
| ٠ | EN 10025-2 | Hot rolled products of structural steels-Part 2: technical | 02.2005 |
| | | delivery conditions for non-alloy structural steels | |
| | | | |


Validity:

Temperature limits: -22°F (-30°C) to 200°F (+93°C). Published allowable loads for applications are based on static loading conditions. Non-static forces, including those resulting from thermal or other expansion must be taken into account during design.



Installation Technical Manual - Technical Data - MI system





| Loading case: Clamped | Combinations covered by loading case |
|--|--|
| Bill of Material for this loading case: | Connector used for an angled connection |
| MIC-SC-MA 304817 Hardware not included in packaging: Beam clamps 4x MI-SGC M12 233859 | of MI-90 to structural steel profiles (bracing). For flange width 9.25 " (235mm) - 11.81" (300mm). |


Usage of Values for Design Strength and Allowable Strength

The Design Strength and Allowable Strength tables on the following pages include strength reduction factors:

- 1. <u>ASD:</u> Safety Factor (omega) > 1.0 as per AISC specifications.
- 2. <u>LRFD</u>: Strength Reduction Factor (phi) < 1.0 as per AISC specifications. $\Omega = \frac{1.5}{\phi}$ (Reference AISC 360 C-B3-5)


Factored loads are required for input to the given interaction equations. Factored loads are the responsibility of the user. Factored loads are noted as P, V and M

Limiting components of capacity evaluated in following tables:



Installation Technical Manual - Technical Data - MI system






Values for Design Strength and Allowable Strength

1/3

NOTE: Calculate interaction separately for each group only using values from that group. Limiter is defined by highest interaction. Use absolute values. Values refer to the coordinate system shown.

1. Connector steel and all connecting hardware



| | +Fx [kip] | -Fx [kip] | +Fy [kip] | -Fy [kip] | +Fz [kip] | -Fz [kip] |
|-------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| | 3.75 | 3.75 | 1.48 | 1.48 | 3.75 | 3.75 |
| LRFD* | +Mx [kip*ft] | -Mx [kip*ft] | +My [kip*ft] | -My [kip*ft] | +Mz [kip*ft] | -Mz [kip*ft] |
| | 0.52 | 0.52 | 0.00 | 0.00 | 0.00 | 0.00 |
| | | | | | | |
| | +Fx | -Fx | +Fy | -Fy | +Fz | -Fz |
| | +Fx [kip] | -Fx [kip] | +Fy [kip] | -Fy [kip] | +Fz [kip] | -Fz [kip] |
| 400* | | | | , | | |
| ASD* | [kip] | [kip] | [kip] | [kip] | [kip] | [kip] |

Note: Design Strength values for girder Torsion about the α x-axis (M_{α x}) are valid for any bracing angle.

Values include verification of hexagonal bolt

Interaction for LRFD


Due to the fact, that the same resistance values as for MIC-CU-MA are decisive, the same interaction formulation can be used:

$$\left[\frac{P_{ux}}{F_x}\right]^2 + \left[\frac{V_{uz}}{F_z}\right]^2 + \frac{V_{uv}}{F_y} + \frac{M_{ux}}{M_x} \le 1$$

Use of $F_{\alpha x}$: In case only the force along the brace axis (αx) is known, determinate load components as follows:

 $\begin{aligned} P_{ux} &= F_{\alpha x} \times \cos \left(\alpha \right) \\ Vuz &= F_{\alpha x} \times \sin \left(\alpha \right) \end{aligned}$

Interaction for ASD:




Use of F_{a} : In case only the force along the brace axis (αx) is known, determinate load components as follows:

 $\begin{aligned} P_{ax} &= F_{\alpha x} \times \cos \left(\alpha \right) \\ Vaz &= F_{\alpha x} \times \sin \left(\alpha \right) \end{aligned}$

*Values already include LRFD strength reduction (Φ) or ASD safety (Ω) factors in accordance with AISC, and are based on nominal geometry.






Values for Design Strength and Allowable Strength

2/3

NOTE: Calculate interaction separately for each group only using values from that group. Limiter is defined by highest interaction. Use absolute values. Values refer to the coordinate system shown.

2. Welds - per analytical calculation +Fx -Fx +Fz -Fz +Εv -Fv [kip] [kip] [kip] [kip] [kip] [kip] 66.29 66.29 3.02 3.02 11.74 11.74 LRFD* +Mx -Mx +My -My +Mz -Mz [kip*ft] [kip*ft] [kip*ft] [kip*ft] [kip*ft] [kip*ft] 1.87 1.87 0.00 0.00 0.00 0.00 +Fx -Fx +Fy -Fy +Fz -Fz [kip] [kip] [kip] [kip] [kip] [kip] 44.19 44.19 7.83 2.01 2 01 7 83 ASD* +Mx -Mx +Mv +Mz -Mz -Mv [kip*ft] [kip*ft] [kip*ft] [kip*ft] [kip*ft] [kip*ft] 1.25 1.25 0.00 0.00 0.00 0.00 Interaction for LRFD Note: Design Strength values for girder Torsion about the x-axis $(M_{\alpha x})$ are valid for any bracing angle. $\frac{P_{ux}}{F_x} + \frac{V_{uz}}{F_z} + \frac{V_{uy}}{F_y} + \frac{M_{ux}}{M_x} \le 1$ Use of $F_{\alpha x}$: In case only the force along the brace axis (αx) is known, determinate load components as follows: $P_{ux} = F_{\alpha x} \times \cos(\alpha)$ $Vuz = F_{\alpha x} x \sin(\alpha)$ Interaction for ASD: $\frac{P_{ax}}{F_x} + \frac{V_{az}}{F_z} + \frac{V_{av}}{F_y} + \frac{M_{ax}}{M_x} \le 1$ Use of $F_{\alpha x}$: In case only the force along the brace axis (αx) is known, determinate load components as follows: $P_{ax} = F_{\alpha x} \times \cos (\alpha)$ $Vaz = F_{\alpha x} \times \sin (\alpha)$ *Values already include LRFD strength reduction (Φ) or ASD safety (Ω) factors in accordance with AISC, and are based on nominal geometry.







Values for Design Strength and Allowable Strength

3/3

NOTE: Calculate interaction separately for each group only using values from that group. Limiter is defined by highest interaction. Use absolute values. Values refer to the coordinate system shown.



Transition of the forces generated on inclined brace to base material connector's coordinate system



| | +Fx [kip] | -Fx [kip] | +Fy [kip] | -Fy [kip] | +Fz [kip] | -Fz [kip] |
|-------|-----------------|--------------------------|-----------------|-----------------|-----------------|-----------------|
| LRFD* | 7.04 | Not decisive | 1.48 | 1.48 | 1.48 | 1.48 |
| | +Mx [kip*ft] | -Mx [kip*ft] | +My [kip*ft] | -My [kip*ft] | +Mz [kip*ft] | -Mz [kip*ft] |
| | 0.66 | 0.66 | 1.50 | 1.50 | 1.96 | 1.96 |
| | | | | | | |
| | +Fx | -Fx | +Fy | -Fy | +Fz | -Fz |
| | +Fx [kip] | -Fx [kip] | +Fy [kip] | -Fy [kip] | +Fz [kip] | -Fz [kip] |
| ASD* | | | , | , | | |
| ASD* | [kip] | [kip] Not | [kip] | [kip] | [kip] | [kip] |
| ASD* | [kip] 4.69 | [kip] Not decisive | [kip] 0.99 | [kip] 0.99 | [kip] 0.99 | [kip] 0.99 |

Interaction for LRFD

Normal force interaction:

The eccentricity ey and ez between the point of force transfer channel / connector and baseplate, which generates an bending moment on the system , must be taken into account in the interaction formula.

$$\frac{P_{ux}}{F_x} + \frac{V_{uy} \times ey}{M_z} + \frac{V_{uz} \times ez}{M_y} + \frac{M_{uz}}{M_z} \le 1$$

with e_v=e_z=0.070 m

with $e_y = e_z = 0.070 \text{ m}$

Shear force interaction:

Shear Interaction Equation is <u>only</u> valid for TENSILE P_{ux} loads (P_{ux} > 0). Equation is <u>not</u> valid for compressive P_{ux} loads (P_{ux} < 0). - For Shear interaction, user must ADDITIONALLY verify: P_{ux} / F_x < 1.

$$\left| \left(\frac{V_{uy}}{F_y \times \left(1 - \frac{P_{ux}}{F_x} \right)} \right)^2 + \left(\frac{V_{uz}}{F_z \times \left(1 - \frac{P_{ux}}{F_x} \right)} \right)^2 + \frac{M_{ux}}{M_x \times \left(1 - \frac{P_{ux}}{F_x} \right)} \le 1$$

Note: Due to the fact, that depending on the inclination of the channel, the acting torsional moment Mox can either generate shear or tension, it will be considered in both interactions.

Interaction for ASD: Normal force interaction:

The eccentricity ey and ez between the point of force transfer channel / connector and baseplate, which generates an additional bending moment on the system , must be taken into account in the interaction formula.

$$\frac{P_{ax}}{F_{y}} + \frac{V_{ay} \times ey}{M_{z}} + \frac{V_{az} \times ez}{M_{y}} + \frac{M_{az}}{M_{z}} \le 1$$

- Shear Interaction Equation is only valid for TENSILE Pax loads (Pax > 0). Equation is not valid for compressive P_{av} loads ($P_{av} < 0$)


For Shear interaction, user must ADDITIONALLY verify:
$$P_{ax} / F_x < 1$$

$$\left| \left(\frac{V_{ay}}{F_y \times \left(1 - \frac{P_{ax}}{F_x} \right)} \right)^2 + \left(\frac{V_{az}}{F_z \times \left(1 - \frac{P_{ax}}{F_x} \right)} \right)^2 + \frac{M_{ax}}{M_x \times \left(1 - \frac{P_{ax}}{F_x} \right)} \le 1$$

*Values already include LRFD strength reduction (Φ) or ASD safety (Ω) factors

in accordance with AISC, and are based on nominal geometry.





| Loading case: Boxed | Combinations covered by loading case |
|--|--|
| Bill of Material for this loading case: 1x MIC-SC-MA 304817 Hardware not included in packaging: Base plate 1x MIB-SC 304823 Threaded rods cut to particular length 4x AM12x1000 8.8 HDGm 419103 Nut | Connector used for an angled connection of MI-90 to structural steel profiles (bracing). For flange width 9.25 " (235mm) - 11.81" (300mm). |
| 8x M12-F-SL WS3⁄4 382897 | |


Usage of Values for Design Strength and Allowable Strength

The Design Strength and Allowable Strength tables on the following pages include strength reduction factors:

- 1. <u>ASD:</u> Safety Factor (omega) > 1.0 as per AISC specifications.
- 2. <u>LRFD</u>: Strength Reduction Factor (phi) < 1.0 as per AISC specifications. $\Omega = \frac{1.5}{\phi}$ (Reference AISC 360 C-B3-5)


Factored loads are required for input to the given interaction equations. Factored loads are the responsibility of the user. Factored loads are noted as P, V and M

Limiting components of capacity evaluated in following tables:



Installation Technical Manual - Technical Data - MI system





Values for Design Strength and Allowable Strength

1/3

NOTE: Calculate interaction separately for each group only using values from that group. Limiter is defined by highest interaction. Use absolute values. Values refer to the coordinate system shown.

1. Connector steel and all connecting hardware

| | +Fx [kip] | -Fx [kip] | +Fy [kip] | -Fy [kip] | +Fz [kip] | -Fz [kip] |
|-------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| LRFD* | 3.75 | 3.75 | 1.48 | 1.48 | 3.75 | 3.75 |
| LRFD | +Mx [kip*ft] | -Mx [kip*ft] | +My [kip*ft] | -My [kip*ft] | +Mz [kip*ft] | -Mz [kip*ft] |
| | 0.52 | 0.52 | 0.00 | 0.00 | 0.00 | 0.00 |
| | | | | | | |
| | +Fx | -Fx | +Fy | -Fy | +Fz | -Fz |
| | +Fx [kip] | -Fx [kip] | +Fy [kip] | -Fy [kip] | +Fz [kip] | -Fz [kip] |
| 400* | | | , | | | . – |
| ASD* | [kip] | [kip] | [kip] | [kip] | [kip] | [kip] |

Note: Design Strength values for girder Torsion about the x-axis ($M_{\alpha x}$) are valid for any bracing angle.

Values include verification of hexagonal bolt

Interaction for LRFD


Due to the fact, that the same resistance values as for MIC-CU-MA are decisive, the same interaction formulation can be used:

$$\left[\frac{P_{ux}}{F_x}\right]^2 + \left[\frac{V_{uz}}{F_z}\right]^2 + \frac{V_{uv}}{F_y} + \frac{M_{ux}}{M_x} \le 1$$

Use of $F_{\alpha x}$: In case only the force along the brace axis (αx) is known, determinate load components as follows:

 $\begin{aligned} P_{ux} &= F_{\alpha x} \times \cos{(\alpha)} \\ Vuz &= F_{\alpha x} \times \sin{(\alpha)} \end{aligned}$

Interaction for ASD:




Use of $F_{\alpha x}$: In case only the force along the brace axis (αx) is known, determinate load components as follows:

 $P_{ax} = F_{\alpha x} \times \cos \left(\alpha \right)$

 $Vaz = F_{\alpha x} x \sin(\alpha)$


*Values already include LRFD strength reduction (Φ) or ASD safety (Ω) factors in accordance with AISC, and are based on nominal geometry.





Values for Design Strength and Allowable Strength

NOTE: Calculate interaction separately for each group only using values from that group. Limiter is defined by highest interaction. Use absolute values. Values refer to the coordinate system shown.



| | +Fx | -Fx | +Fy | -Fy | +Fz | -Fz |
|-------|----------------|----------------|---------------|---------------|---------------|---------------|
| | [kip] | [kip] | [kip] | [kip] | [kip] | [kip] |
| | 66.29 | 66.29 | 3.02 | 3.02 | 11.74 | 11.74 |
| LRFD* | +Mx | -Mx | +My | -My | +Mz | -Mz |
| | [kip*ft] | [kip*ft] | [kip*ft] | [kip*ft] | [kip*ft] | [kip*ft] |
| | 1.87 | 1.87 | 0.00 | 0.00 | 0.00 | 0.00 |
| | | | | | | |
| | | | | | | |
| | +Fx | -Fx | +Fy | -Fy | +Fz | -Fz |
| | +Fx [kip] | -Fx [kip] | +Fy [kip] | -Fy [kip] | +Fz [kip] | -Fz [kip] |
| | | | , | , | | |
| ASD* | [kip] | [kip] | [kip] | [kip] | [kip] | [kip] |
| ASD* | [kip] 44.19 | [kip] 44.19 | [kip] 2.01 | [kip] 2.01 | [kip] 7.83 | [kip] 7.83 |

Interaction for LRFD

Note: Design Strength values for girder Torsion about the x-axis (M_{ax}) are valid for any bracing angle.

$$\frac{P_{ux}}{F_x} + \frac{V_{uz}}{F_z} + \frac{V_{uy}}{F_y} + \frac{M_{ux}}{M_x} \le 1$$

Use of $F_{\alpha x}$: In case only the force along the brace axis (αx) is known, determinate load components as follows:

 $P_{ux} = F_{\alpha x} \times \cos(\alpha)$

 $Vuz = F_{\alpha x} x \sin(\alpha)$

Interaction for ASD:


$$\frac{P_{ax}}{F_x} + \frac{V_{az}}{F_z} + \frac{V_{ay}}{F_y} + \frac{M_{ax}}{M_x} \le 1$$

Use of $F_{\alpha x}$: In case only the force along the brace axis (αx) is known, determinate load components as follows:

 $P_{ax} = F_{\alpha x} \times \cos (\alpha)$ $Vaz = F_{\alpha x} \times \sin (\alpha)$


*Values already include LRFD strength reduction (Φ) or ASD safety (Ω) factors in accordance with AISC, and are based on nominal geometry.






Values for Design Strength and Allowable Strength

NOTE: Calculate interaction separately for each group only using values from that group. Limiter is defined by highest interaction. Use absolute values. Values refer to the coordinate system shown.



Transition of the forces generated on inclined brace to base material connector's coordinate system



| | +Fx [kip] | -Fx [kip] | +Fy [kip] | -Fy [kip] | +Fz [kip] | -Fz [kip] |
|-------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| LRFD* | 9.85 | Not decisive | 2.07 | 2.07 | 2.07 | 2.07 |
| | +Mx [kip*ft] | -Mx [kip*ft] | +My [kip*ft] | -My [kip*ft] | +Mz [kip*ft] | -Mz [kip*ft] |
| | 0.90 | 0.90 | 1.94 | 1.94 | 2.74 | 2.74 |
| | | | | | | |
| | +Fx [kip] | -Fx [kip] | +Fy [kip] | -Fy [kip] | +Fz [kip] | -Fz [kip] |
| 4 SD* | | | , | , | | |
| ASD* | [kip] | [kip] Not | [kip] | [kip] | [kip] | [kip] |

Interaction for LRFD

Normal force interaction:

The eccentricity ey and ez between the point of force transfer channel / connector and baseplate, which generates an additional bending moment on the system , must be taken into account in the interaction formula. V $+\frac{M_{uz}}{M} \le 1$ × 011 X P7

$$\frac{F_{ux}}{F_{u}} + \frac{V_{uy} \times ey}{M_{-}} + \frac{V_{uz} \times ez}{M_{-}} + \frac{V_{uz}$$

with e_v=e_z=0.070 m

with $e_y = e_z = 0.070 \text{ m}$

Shear force interaction:

- Shear Interaction Equation is <u>only</u> valid for TENSILE P_{ux} loads (P_{ux} > 0). Equation is <u>not</u> valid for

 $\begin{array}{c} \label{eq:compressive} compressive P_{ux} (loads (P_{ux} < 0). \\ \mbox{For Shear interaction, user must ADDITIONALLY verify: } P_{ux} / F_x < 1. \end{array}$

$$\left| \left(\frac{V_{uy}}{F_y \times \left(1 - \frac{P_{ux}}{F_x} \right)} \right)^2 + \left(\frac{V_{uz}}{F_z \times \left(1 - \frac{P_{ux}}{F_x} \right)} \right)^2 + \frac{M_{ux}}{M_x \times \left(1 - \frac{P_{ux}}{F_x} \right)} \le 1$$

Μ,

Note: Due to the fact, that depending on the inclination of the channel, the acting torsional moment Max can either generate shear or tension it will be considered in both interactions.

Interaction for ASD: Normal force interaction:

The eccentricity ey and ez between the point of force transfer channel / connector and baseplate, which generates an additional bending moment on the system , must be taken into account in the interaction formula.

$$\frac{P_{ax}}{F_{y}} + \frac{V_{ay} \times ey}{M_{z}} + \frac{V_{az} \times ez}{M_{y}} + \frac{M_{az}}{M_{z}} \le 1$$

Shear force interaction:

- Shear Interaction Equation is only valid for TENSILE Pax loads (Pax > 0). Equation is not valid for compressive P_{ax} loads ($P_{ax} < 0$). - For Shear interaction, user must ADDITIONALLY verify: $P_{ax} / F_x < 1$.

$$\left(\frac{V_{ay}}{F_y \times \left(1 - \frac{P_{ax}}{F_x} \right)} \right)^2 + \left(\frac{V_{az}}{F_z \times \left(1 - \frac{P_{ax}}{F_x} \right)} \right)^2 + \frac{M_{ax}}{M_x \times \left(1 - \frac{P_{ax}}{F_x} \right)} \le 1$$

*Values already include LRFD strength reduction (Φ) or ASD safety (Ω) factors in accordance with AISC, and are based on nominal geometry.



Installation Technical Manual - Technical Data - MI system



In the US: Hilti, Inc. (U.S.) P.O. Box 21148 Tulsa, OK 74121 Customer Service: 1-800-879-8000 en español: 1-800-879-5000 Fax: 1-800-879-7000

www.us.hilti.com

Hilti is an equal opportunity employer Hilti is a registered trademark of Hilti, Corp. ©Copyright 2017 by Hilti, Inc. (U.S.)

In Canada:

Hilti (Canada) Corporation 2360 Meadowpine Blvd. Mississauga, Ontario, L5N 6S2 Customer Service: 1-800-363-4458 Fax: 1-800-363-4459

www.hilti.ca

The data contained in this literature was current as of the date of publication. Updates and changes may be made based on later testing. If verification is needed that the data is still current, please contact the Hilti Technical Support Specialists at 1-800-879-8000 (U.S.) or 1-800-363-4458 (Canada). All published load values contained in this literature represent the result of testing by Hilti or test organizations. Local base materials were used. Because of variations in materials, on-site testing is necessary to determinate performance at any specific site.